

# Relay protection CT ratio



## Overview

Selecting the appropriate CT ratio is a crucial step in CT design! It is influenced by two key factors: the maximum load current and the maximum short circuit current. For example, a 400:5 CT steps down 400 Amps to 5 Amps—an 80:1 reduction. This allows high currents to be safely measured with standard 5-Ampere meters. Primary Current = Secondary Current  $\times$  Turns Ratio These CTs are commonly used for residential, light commercial, and branch circuit monitoring. 1 Parameters for CT Sizing The CT nameplate data. Plug setting multiplier of relay is referred as ratio of fault current in the relay to its pick up current. Suppose we have connected on protection CT of ratio 200/1 A and current setting is 150%. Hence, fault current in the CT secondary. Quick Definition: Current transformer sizing is the process of selecting a CT ratio, burden, and accuracy class that converts primary current to a manageable secondary value without exceeding saturation or thermal limits, following IEC 61869 and IEEE C57.



## Article Content

### CT Sizing for Generator and Transformer Protective Relays

Using CT models that were validated with a physical CT, along with simulations and hardware-in-the-loop testing, we determined the CT requirements for a generator and transformer differential scheme

### Impact of CT saturation on overcurrent relays

An important issue for a protection relay is how it responds when the steel core of the CT is saturated. The exact behaviour of a CT depends on

### Sizing Current Transformers for Line Protection Applications

Héctor J. Altuve, Normann Fischer, Gabriel Benmouyal, and Dale Finney, Schweitzer Engineering Laboratories, Inc. current transformers (CTs) for line protection applications. We first cover CT

### CT Sizing for Generator & Transformer Protective

Explore CT sizing guidelines and relay settings for generator and transformer differential protection. This paper covers IEEE/IEC guidance, CT

### Current Transformer Sizing Best Practices for Reliable Protection

CT mis-sizing leads to nuisance trips, inaccurate billing, and compromised safety. This guide provides a structured approach to selecting ratios, burdens, and thermal ratings validated by

### CT Ratio Chart: Standard Ratios from 5/5 to 6000/5

Complete CT ratio chart with standard ratios for metering and protection CTs. Includes primary current ranges, accuracy class recommendations, and

### CT selection for Arcteq relays

On the other hand, a CT failure must be detected in order to block the relay and to avoid the relay's false operation during external faults. For this reason, another sensitive high-impedance differential

### Minimum CT Ratio Calculation for Distribution Transformer Protective Relays

This calculator determines the minimum CT ratio required for protective relay settings in a distribution transformer. Explanation Calculation Example: The minimum CT ratio required for

### Plug settings (PS) and CT ratios of the relays (Case 1).

Download scientific diagram | Plug settings (PS) and CT ratios of the relays (Case 1). from publication: Hybridization of PSO for the Optimal Coordination of Directional Overcurrent Protection ...

## 51 Relay Setting vs. CT Ratio

SKM and some other publications recommend selecting the CT ratio on the primary side of a transformer to be 200% of transformer FLA base rating and to set the 51 pickup at 110-140% of

Microsoft Word

Impact of CT Errors on Protective Relays – Case Studies and Analysis Rich Hunt, Lubo Sevov, Iliia Voloh - GE Multilin Current transformers (CTs) are the basic interconnection between the power

### CT RATIO (CTR)

CT RATIO (CTR) Current transformers are used to scale down the primary currents to small magnitudes so that they can be safely applied to protective relays. Figure 3.1 represents an equivalent circuit of a

About CT and relay performance | Eng-Tips

Will the saturation cause the relay to fail to operate? Doesn't matter how saturated if the relay still does its job. Why do you need to see load with your protection CT? Why does the relay

### CTs in Power System Protection

Install CTs with identical accuracy class and ratio on each end of the protected element or apply ratio correction in the relay configuration. Verify CT

### SELECTION OF CURRENT TRANSFORMERS & WIRE SIZING IN

As we will see further, choosing a higher CT ratio increases the available knee point voltage to the relay, but the secondary current gets reduced greatly. The latter could be an issue where load matched

### CT Sizing for Generator and Transformer Protective Relays

CT SIZING FOR GENERATOR AND TRANSFORMER PROTECTIVE RELAYS Ritwik Chowdhury<sup>1\*</sup>, Dale Finney<sup>1</sup>, Normann Fischer<sup>1</sup>, Douglas Taylor<sup>2</sup> 1Schweitzer Engineering Laboratories, Inc.,

### CT sizing for generator and transformer protective relays

Modern relays often have algorithms that enhance the security of elements that are otherwise susceptible to current transformer (CT) saturation. In this paper, we consider some of the similarities

Never underestimate how important it is to choose the right CT ...

This article focuses on the calculation of CT sizing specifically for dual power overcurrent relays, aiming to ensure effective protection and fault detection in power systems.

## Compensating CT Ratio Mismatch | Differential Protection

Compensating CT ratio mismatch is a very important step in configuring a differential protection. This may be achieved by specifically

CT sizing for generator and transformer protective relays

Then using these models, we determine CT sizing guidelines and relay settings for a generator and transformer differential relay. Application

### Determining CT Requirements for Generator and Transformer Protective Relays

We consider CT models and compare the various models commonly available to laboratory test data to provide insight into the model parameters and confirm the model validity.

### Current Transformers for Protection Relays

The “C” Class rating of a protection CT is usually shown next to the CT ratio on drawings and performance charts, and is a value in volts. For example, a CT labeled “600:5 C100” has a ratio  $N =$

### APPLICATION BOOK CT REQUIREMENTS FOR GE MULTILIN

Before to initiate the development of this interesting subject, we would like to clarify certain myths over CT calculation that still exist among the protection relay professionals:

#### Selecting CTs to Optimize Relay Performance

Using this information, we relate the fault current, the CT burden, and the system X/R ratio in an expression, which ultimately determines the useful range in any CT. The paper then identifies the

#### Pick Up Current | Current Setting | Plug Setting

Plug setting multiplier of relay is referred as ratio of fault current in the relay to its pick up current. Suppose we have connected on protection CT of

## Contact Us

For more information, pricing, or custom solutions, please contact us:

Website: <https://www.boxesgaramella-andria.it>

Email: [sales@boxesgaramella-andria.it](mailto:sales@boxesgaramella-andria.it)

Phone: +39 331 584 7291

Address: Via delle Industrie, 15, 20154 Milano, Italy

This document is for informational purposes only. Specifications subject to change without notice.

